


STRAIGHT SHOT™ MOUNTING INSTRUCTIONS

Rebounders with Straight Shot Hole Pre-Drilled

Before working on your planter or drill

DANGER: When storing or working on the planter or drill always install cylinder stops or place it on stands to prevent personal injury or damage to the attachments.

PLEASE: Read instructions completely and verify all package contents before beginning installation.



Straight Shot Package Contents part # SSK (per single row)	
Item	Quantity
Straight Shot	1
Threaded Female QC	1
1/4" Hose	1
Metal Plate	1
L-Bracket	1
Washer	1
Propeller T Nut	1
Screw for T Nut Slotted	1
12 x 3/8" Screws	2
Instruction Sheet	1

- 1 Take the propeller t-nut (fig. A) and insert it into the back side of one of the upper holes of the drill Rebounders (fig. B) or into the hole on the back side of the sawtooth insert on the OJD John Deere planter type Rebounder.
- 2 Place the L-bracket (fig. D) with the small hole down on the Rebounder with the washer (fig. E) on top, over the hole of the propeller t-nut.
- 3 Using screwdriver, tighten the round-head slotted 10-24 x 3/8" screw (fig. F) into the propeller t-nut.
- 4 Thread the 1/4" tube x 1/8" female NPTF (fig. G) into the Straight Shot.
- 5 Place the Straight Shot between the moded tabs. Place the plate over the Straight Shot and install the two #12 x 3/8" pan phillips type screws (fig. J).
- 6 Run the hose through the L-bracket on the Rebounder and push the hose into the Quick Coupler on the Rebounder. To remove hose from the Quick Coupler, press ring down around the hose against the Quick Couple so that the hose will release (fig. K).
- 7 Follow Rebounder Mounting Instructions for mounting the Rebounder.

