

JD/STN PRESS WHEEL STOP

John Deere 1590 1690 1890 1990 Drills with 10" Press Wheels

Before working on your planter or drill

DANGER: When storing or working on the planter always install cylinder stops or place the planter on stands to prevent personal injury or damage to the attachments.


PLEASE: Read instructions completely and verify all package contents before beginning installation

NOTE:

- ! Does not work with John Deere 750 drills or any JD 50 and 60 series drills
- ! Use with 10" press wheels only

| JD/STN PRESS WHEEL STOP Package Contents (per single row) | |
|--|-----|
| Item | Qty |
| JD/STN Press Wheel Stop | 1 |
| Instruction Sheet | 1 |

Using original hardware, slip the JD/STN Press Wheel Stop in under the closing wheel arm to hold it up off the 10" press wheel fertilizer tube attachments.



| JOHN DEERE DRILL ATTACHMENT OPTIONS | |
|-------------------------------------|---------------------------|
| A | REBOUNDER |
| B | CHAD'S TUBE |
| C | PRESS WHEEL STOP DJDCS |
| D | TUBE OVER THE PRESS WHEEL |
| E | PRESS WHEEL STOP JD/STN |
| F | MVP CLOSING WHEEL |