

PRESS WHEEL SCRAPER MOUNTING INSTRUCTIONS

Great Plains

(Read Instructions Completely before Beginning Installation)

Before working on your planter or drill




DANGER: When storing or working on the planter or drill always install cylinder stops or place the planter on stands to prevent personal injury or damage to the attachments.

Mounting Instructions

Before you begin, verify all items listed in the "package contents" table at the right.

Step #1: Bolt scraper to bracket using carriage bolts and whiz nuts. Do not tighten too much so that the scraper can be positioned to fit the contour of the tire. You will want about 1/4" of gap between the scraper and tire.

Step #2: Remove the bolt from the center of your press wheel and place the scraper bracket on the outside of the press wheel. The bracket should run in approximately the 11 o'clock position on the outside of the wheel. Replace the bolt and tighten.

Great Plains Gauge Wheel Scraper Package Contents (per side)	
Item	Quantity
	2
	2
Scraper.....	1
	1
Instruction Sheet.....	1

