

PUMP SYSTEM MOUNTING INSTRUCTIONS

Pressure Gauge

Before working on your planter or drill

DANGER: When storing or working on the planter always install cylinder stops or place the planter on stands to prevent personal injury or damage to the attachments.

PLEASE: Read instructions completely and verify all package contents before beginning installation.

Pressure gauge is pre-assembled and built into the manifold.



Pressure gauge assembly options

DIRECT TO MANIFOLD



optional REMOTE PRESSURE GAUGE KIT

The remote pressure gauge kit includes a bracket and magnet (Magmount) so the pressure gauge can be easily mounted to the most visible location on your equipment.


The bracket is adjustable so that the Magmount can be placed on the top or the side of a metal frame.



Side mount gauge & Magmount



Top mount gauge & Magmount



Run the 1/4" black tubing from the mounted pressure gauge to quick connect on the 3/4" tee assembly that taps into the system's main plumbing.

This tee assembly connects the 3/4" black rubber hose coming from the 80 mesh filter on the main tower to the 3/4" black rubber hoses running to the wing manifolds.

