

Y-NOT SPLIT-IT MOUNTING INSTRUCTIONS

Optional Fitting for Rebounders
(Read Instructions Completely before Beginning Installation)


Mounting Instructions

Before you begin locate the "package contents" list to verify all items are included.

- Step #1:** take the propeller t-nut (**fig. (a)**) and insert it into the hole on the backside of the Rebounder saw tooth insert (**fig. (b)**) using a hammer or pliers to press it into the plastic.
- Step #2:** turn the saw tooth over placing it into the Rebounder (see Rebounder mt. instructions for proper placement of the saw tooth). Now place the L-bracket (**fig. (c)**) with the small hole on the Rebounder with the washer (**fig. (d)**) on top, over the hole of the propeller tee nut.
- Step #3:** using a screw driver, tighten the round-head, slotted (10-24 x 3/8") screw (**fig. (e)**) into the propeller t-nut.
- Step #4:** using a hair dryer on low or medium setting, briefly heat the short piece of clear hose. Quickly push heated end of this hose all the way over the barbed end of the "Y" (**fig. (f)**).
- Step #5:** install the clear hose and "Y" between the raised area that holds the screws. The "Y" should bump up against the molded-in tab (**fig. (g)**).
- Step #6:** place the metal plate over the clear hose and install the 2# 12x3/8" Pan Phillips type screw into the holes of the Rebounder.
- Step #7:** after mounting the first Rebounder with the Y-Not check to make sure that the outlets on the Y-Not do not extend past the edge of the Rebounder. Trim with a side dike (**fig. (h)**). Clean out the holes with a pocket knife after clipping, this will keep the Y-Not from plugging.
- Step #8:** if you prefer to have the fertilizer closer to the bottom of the seed furrow you can cut the molded in tabs off (**fig. (i)**). Slide the Y-Not closer to the end of the Rebounder before tightening the screws on the metal plate. Then refer to step 7. Normally this is only done for inoculants. Refer to Hose Holder Instructions as it will do what cutting tab off will do.

Important Points to Remember:

- do not over-tighten or bottom out the screws into the Rebounder as this can damage the plastic.
- **IMPORTANT!! Do not strap any large tie around any part of the hose**, this 1/4" hose must be able to flex with the Rebounder independently. Hose holder kits are available for securing the hose.
- **NOTE: screws shown below come in the Rebounder Kit.**



Y-Not Split-It Package Contents for JD type (per single row)	
Item	Quantity
"Y"	1
1/4 Black Hose	1
3/8" Clear Hose.....	1
Metal Plate.....	1
L-Bracket	1
Washer	1
Propeller T-Nut.....	1
Screw for T-Nut Slotted	1
Instruction Sheet	1

Y-Not Split-It Package Contents for IH 800/900 type (per single row)	
Item	Quantity
"Y"	1
1/4 Black Hose	1
3/8" Clear Hose.....	1
Tie Strap.....	1
Metal Plate.....	1
Tube Clamp	1
Instruction Sheet	1

Y-Not Split-It Package Contents for IH 1200 type (per single row)	
Item	Quantity
"Y"	1
1/4 Black Hose	1
3/8" Clear Hose.....	1
Tie Strap.....	1
Metal Plate.....	1
Instruction Sheet	1

Rebounder covered by one or more of the following U.S. patents: 5,640,915; 5,918,557; 6,082,275; 6,283,050; 6,453,832; 6,763,773 and 7,121,216.

HOSE HOLDER MOUNTING INSTRUCTIONS

Optional Fitting for Rebounders
 J.D., Kinze, White, Yetter, Great Plains, and Monosem Planters
 (Read Instructions Completely before Beginning Installation)

Important Points to Remember before you begin:

- The holder in this kit acts as a guide keeping the disc from rubbing on the 1/4" fertilizer or chemical hose.
- The Hose Holder must be mounted to the Rebounder before the Rebounder is attached to the seed tube.
- **IMPORTANT!! Do not strap any large tie around any part of the hose**, this hose must be able to flex with the Rebounder independently.

Hose Holder Package Contents for JD type (per single row)	
Item	Quantity
3/8" Clear Hose	1
1/4 Black or Gray Hose	1
Metal Plate	1
Propeller T-Nut	1
Washer	1
L Bracket	1
Screw for T-Nut Slotted	1
Instruction Sheet	1

Mounting Instructions

Before you begin locate the "package contents" list to verify all items are included.

- Step #1:** take the propeller t-nut (**fig. (a)**) and insert it into the hole on the backside of the Rebounder saw tooth insert (**fig. (b)**) using a hammer or pliers to press it into the plastic.
- Step #2:** turn the saw tooth insert over placing it into the Rebounder (see Rebounder mt. instructions for proper placement of the saw tooth). Now place the L-bracket (**fig. (c)**) with the small hole on the Rebounder with the washer (**fig. (d)**) on top, over the hole of the propeller tee nut.
- Step #3:** using a screw driver, tighten the round-head, slotted (10-24 x 3/8") screw (**fig. (e)**) into the propeller t-nut.
- Step #4:** attach Rebounder to the seed tube (see Rebounder mt. instructions for your planter type).
- Step #5:** slice through one side of the short piece of clear plastic hose (lengthwise), then place it over the 1/4" gray or black hose about 2" from end of 1/4" hose (**fig.(f)**). In order to run the fertilizer or chemical hose to the end of the Rebounder you must first run the hose through the large hole on the L-bracket (**fig. (g)**). Run the tube through the raised area that holds the screws and the hole in the molded-in tab at the end of the Rebounder. **Extend the hose past the end of the Rebounder tip approximately 3/8".**
- Step #6:** Place the screws in the metal plate, over the clear hose that is over the gray or black hose and screw the metal plate down to the Rebounder to hold the hose in place (**fig. (h)**). **NOTE: screws shown below come in the Rebounder Package.**

