

# Y-NOT SPLIT-IT® MOUNTING INSTRUCTIONS

## for Planters with John Deere type Rebounder

**Before working on your planter or drill**

**DANGER:** When storing or working on the planter always install cylinder stops or place the planter on stands to prevent personal injury or damage to the attachments.

**PLEASE:** Read instructions completely and verify all package contents before beginning installation.

**! ATTENTION !**

**Use the Yellow "Y" if you are applying less than 6 GPA.  
They are half the size of the clear "Y" in the package.**

Y-Not for JD type	
PART # <b>3Y</b>	Package Contents (per single row)
Item	Quantity
Clear "Y" . . . . .	1
Yellow "Y" . . . . .	1
1/4" Gray Hose . . . . .	1
3/8" Clear Hose . . . . .	1
Metal Plate . . . . .	1
12x3/8" Phillips Screws . . . . .	2
L-Bracket . . . . .	1
Washer . . . . .	1
Propeller T-Nut . . . . .	1
Screw for T-Nut Slotted . . . . .	1
Instruction Sheet . . . . .	1

**Step #1:** Take the propeller t-nut (**fig. (a)**) and insert it into the hole on the backside of the Rebounder saw tooth insert (**fig.(b)**) using a hammer or pliers to press it into the plastic.

**Step #2:** Turn the saw tooth over, placing it into the Rebounder (see Rebounder mt. instructions for proper placement of the saw tooth). Now place the L-bracket (**fig.(c)**) with the small hole on the Rebounder with the washer (**fig. (d)**) on top, over the hole of the propeller t-nut.

**Step #3:** Using a screw driver, tighten the round-head, slotted (10-24 x 3/8") screw (**fig.(e)**) into the propeller t-nut.


**Step #4:** Using a hair dryer on low or medium setting, briefly heat the short piece of clear hose. Quickly push heated end of this hose all the way over the barbed end of the "Y".

**Step #5:** Install the clear hose and "Y" between the raised area that holds the screws. The "Y" should bump up against the molded-in tab (**fig. (g)**).

**Step #6:** Place the metal plate over the clear hose and install the two #12 x 3/8" Pan Phillips type screw into the holes of the Rebounder.

**Step #7: If you are putting "Y's" on worn Rebounders:** after mounting the first Rebounder with Y-Not, check to make sure that the outlets on the Y-Not do not extend past the edge of the Rebounder. Trim with a side dike (**fig. (h)**). Clean out the holes with a pocket knife after clipping; this will keep the Y-Not from plugging.

**Step #8:** If you prefer to have the fertilizer closer to the bottom of the seed furrow you can cut the molded-in tabs off (**fig. (i)**). Slide the Y-Not closer to the end of the Rebounder before tightening the screws on the metal plate. Then refer to step 7. Normally this is only done for inoculates. Refer to Hose Holder Instructions as it will do what cutting the tab off will do.



**Important Points to Remember:**

- Do not over-tighten or bottom out the screws into the Rebounders as this can damage the plastic.
- **IMPORTANT!! Do not strap any large tie around any part of the hose.** This 1/4" hose must be able to flex with the Rebounder independently. House holder kits are available for securing the hose.

